

Espresso ne EM- 1040

Start Up
Instructions



Using Drip Coffee Side

- Note: that you can only use one side of this unit at a time.
- To use the drip coffee side press the top lid (G) on the front and back on the left side to release to top lid and open. Fill the glass carafe (B) with water and pour it in the left side (E). Then you can press the lid back down and lock the lid by pressing front and back.
- Use a paper filter and fill with coffee and place in the filter cone (D). Make sure not to get any coffee grinds in the water tank area as this can cause a blockage in the unit.

A close-up photograph of a hand holding the top lid of a coffee machine. The hand is positioned on the left side of the lid, which is being lifted. In the background, a glass carafe is visible, showing measurement markings. The carafe has a 'MAX' line at 15 and another line at 10. Other markings include 12, 8, 9, 6, and 4. The word 'FLEXIBLE' is overlaid in large white letters across the middle of the image.

FLEXIBLE

The coffee side makes up to
our favorite coffee.



FLEXIBLE

The coffee side makes up to 10 cups of your favorite coffee.

Using Drip Coffee Side

- Make sure (h7) bottom switch is OFF (to the left). To turn on the drip coffee side, you slide the switch at the top (h2) to the right. This will start the coffee brewing process. The light (h1) will start to blink as the coffee is being made. The water will start to heat and brew the pot of coffee. When done, you can leave the glass on the warmer to keep the coffee warm.

Using the Espresso Side

- Make sure the top switch (h2) is to the LEFT and off. Make sure h5 switch is to the LEFT.
- Pull the water tank forward and fill with water to the max line and push firmly back into place.
- First time using the machine you will want to prime the unit. You may also have to do this from time to time if air gets into the unit and you are not getting water /espresso to flow.



Using the Espresso Side

- Turn (h7) switch to the right and the blue light will flash slowly. Once it is solid, place a cup under the frother nozzle and rotate the knob on the right side of the unit away from you toward d2/d3. Once you do this you will hear the pump come on and water should start to come out. You will also get some steam but wait until you see a steam of water and fill $\frac{1}{2}$ a cup and then rotate the knob forward back to pending d1.





Using the Espresso Side

- Now your unit is ready to make espresso.
- Take the filter holder (O) and place one of the baskets for 1 or 2 cups (q / r) into the handle. Then fill with espresso grinds with the spoon (s) for 1 or 2 scoops and use the tamper end of (t) to press down on the grinds.
- Place the filter holder onto the unit and rotate to the right until tight. It is ok if it is pulled off center to the right to make sure it is tight.

Using the Espresso Side

- Now you have the option of making 1 or 2 cups. Please note that these 2 switches are programmable. They are factory set but you can change. To start the espresso making, simply press and release your finger on either switch. You will hear the pump come on and then go off for pre-wetting and then a few seconds the pump will come on again and espresso will start to flow into your cup. It will automatically shut off when the level is reached.
- Note that you can also raise and lower the cup holder by pressing the 2 circles on the drip tray to raise or press down to lower.





Using the Espresso Side

- If you want to change the amount of espresso being made, you would simply set up the holder with coffee and put on the unit and press and HOLD the switch (either 1 or 2 cup) over to the right. Keep holding until it fills the cup to the level you like and then release your finger. This is now memorized. You can change at any time doing the same process.

Frothing Milk

- If you would like to steam milk for your espresso drink please do the following.
- Make sure the filter holder with the espresso is off the unit when you do this.
- Turn the switch (h5) to the right. The blue light will flash. Once solid you can place your milk pitcher under the frother nozzle and rotate the knob away from you to d3. Use a circular and up and down motion to froth your milk. When done, rotate the knob back to d1 pending position.
- After you are done, remove the frother cover and clean any milk away with damp cloth. Also good to run hot water out of the frother so it does not dry and clog the nozzle.





Making hot water

- If you want to make hot water. With h5 switch to the left, rotate the knob to d3 away from you and water will flow out of the frother. Turn back to d1 pending to stop the process.

TROUBLESHOOTING

- Note: you can only use 1 side at a time. If using the drip side make sure h2 is to the right (on) and h7 is to the left (off)
- If you are not getting water to flow out of the espresso side: you may need to prime the unit. Sometimes air locks can be stubborn. When set up to make espresso with the filter holder off the unit, rotate the knob to the back position and you should get water to come out. If you do not pull the water tank out while the pump is running and push back in and it should grab and pull water through the unit. You may need to do this 2-3 times to grab the water.

