


Replacing the FLOWMETER

www.electra-craft.com



After removing the top housing you will see the flowmeter.

Remove the wire connection from the PCB and then the 2 hoses that go to the flowmeter. Then remove the 2 screws and you can pull out the flowmeter and install the new one and put the tubes back on and tighten all.